

Braided sleeve pulling system disassembly procedure

This manual goes over the disassembly procedure of our braided sleeve pulling system (later just sleeve).

Remove heat shrink at end of sleeve with knife without damaging cable inside.



Pull opened sleeve towards other end of cable until section with insulation tape is visible.



Remove insulation tape and plastic loop, then pull whole sleeve off.



Remove bubble wrap by pulling towards end where bubble wrap is sealed.

